



## IEI 2000 Series Keypad

Setting the IEI 2000 Series Keypad For eIDC: This would be right out of the box setup. So if they have made changes you may want to reset the IEI keypad. Enter Program Mode. Press: **99 # master code \***  
Then enter: **46 # 00000 # 00000 # \*\***

### 1: Set IEI for Wiegand Front End Mode

1. Enter Program Mode.  
Press: **99 # master code \* (default 1234)**  
Yellow LED Flashes Slowly  
2. Select Wiegand Front End Mode  
Press: **1032 # 0 # 1 # \*\***  
Yellow LED Flashes Slowly  
3. Exit Program Mode  
Press **\***  
The Yellow LED Stops Flashing

Setting site code:

2: Enter Program Mode \*  
Press: **99 # master code \***  
Yellow LED Flashes Slowly

Press : **34 # 0 # (enter the site code here) # \*\***

Wiring the Date to the Eidc:

White/Black Wiegand Data 0  
White/Yellow Wiegand Data 1